


Quickstart CADnetwork® RenderCube®

1

Connect the RenderCubes with Power Cord and Network



2

Search the RenderCubes with RenderCube Remote Tool




RenderCube Remote.exe



3

Start the Connection with rightclick on the RenderCube and **RDP**



Authentication:

User: **CADuser**

Password: **CADnetwork**

